

# DMX-CHART SUNBEAM 100 TWO WHITE

CHANNEL	VALUE	FUNCTION
1	0..255	MASTERDIMMER HIGHBYTE
2	0..255	MASTERDIMMER LOWBYTE
3	0..255	STROBO SPEED
4	0..255	STROBO DURATION
5	0..255 0..5 6..10 11..15 16..20 21..245 246..250 251..255	GAMMA & MODE SELECTION  16 BIT, NO GAMMA, 1 GROUP 8 BIT GAMMA 1 FIX , 1 GROUP 8 BIT GAMMA 2 FIX, 1 GROUP 8 BIT GAMMA 3 FIX, 1 GROUP 8 BIT GAMMA JUSTABLE, 1 GROUP 8 BIT GAMMA 1 FIX, 2 GROUPS 8 BIT GAMMA 1 FIX, 4 GROUPS
6	0..255	COOL WHITE HIGH BYTE / GROUP1
7	0..255	WARM WHITE HIGH BYTE / GROUP1
8	0..255	COOL WHITE LOW BYTE / GROUP1 OR HIGH BYTE GROUP 2
90	0..255	WARM WHITE LOW BYTE / GROUP1 OR HIGH BYTE GROUP 2
10	0..255	COOL WHITE HIGH BYTE / GROUP3
11	0..255	WARM WHITE HIGH BYTE / GROUP3
12	0..255	COOL WHITE BYTE / GROUP4
13	0..255	WARM WHITE HIGH BYTE / GROUP4
		<b>CHANNELS 10-3 ONLY IN USE IF SELECTED BY MODE CHANNEL 6 ! OTHERWISE THESE CHANNELS CAN BE USED FOR OTHER FIXTURES!</b>